

Typical Cascade control diagram

Example 20, 21, 22 - Heat, closed loop, PID control with remote SP using cascade heat control of process with long lag time

Real world use is to use two loops of control. An outer loop feeds an inner loop to account for long lag time to achieve product temperature.

