

Typical Sensor Backup diagram

Example 12 - Heat, closed loop, PID control without remote set point controlling to a working sensor. If sensor A fails, sensor B is used.

Real world use is to ensure redundant sensors are available to ensure the process continues even when a sensor fails.

Demonstrates use of 2 sensors, Analog Input, PV, Control, and Output Analog Function Blocks

